



NEED HELP?



Catalog No: 15-4320

[Soil-borne Cereal Mosaic Virus (SbCMV) Probe Realtime RT-PCR Kit]

User Manual

Disclaimer: Products are intended for research use only

skygen

Biofargo

 www.biofargo.com

 804-529-2296

 contact@biofargo.com



Product Description

Soil-borne Cereal Mosaic Virus (SbCMV) Probe Realtime RT-PCR Kit is designed for the quantitative detection of Soil-borne Cereal Mosaic Virus (SbCMV) specific RNA in a real-time RT-PCR test using hydrolysis probes. Purified RNA is reverse transcribed to cDNA and subsequently amplified using a pair of primers. In the amplification process, Taq DNA polymerase amplifies the cDNA sample via quantitative PCR using a primer-probe set that targets a SbCMV specific cDNA region. At each cycle of the PCR, the 5' nuclease activity of Taq DNA polymerase degrades the bound probes, releasing the quenched SbCMV-specific FAM signal. The increase in FAM fluorescence measures the amplifications. At a point where the fluorescence signal is confidently detected over the background signal, a Ct value can be determined for the FAM signal. This Ct parameter can be used to evaluate relative target abundance among samples. Soil-borne Cereal Mosaic Virus (SbCMV) Probe Realtime RT-PCR Kit has the following features:

1. One-tube RT-PCR, minimized carry-over contamination.
2. High sensitivity, with an analytical LOD at 100 copies/reaction.
3. High specificity, no cross-reaction with RNA from other pathogens.
4. Amplification positive control is provided in the kit.
5. Compatible with various RNA purification methods.
6. Suitable for both qualitative and quantitative detection. For quantitative use, the linear range is at least 5 orders of magnitude.
7. Enough for 50 reactions, 20 µL per reaction.
8. Research use only.

Input Sample Requirements

Highly suggest to use RNA purified with Qiagen QIAamp Viral RNA Mini Kit or Thermo Fisher MagMAX Viral/Pathogen Nucleic Acid Isolation Kit.

Kit Components

Component Name	Product Number.	Size	Vial	Lid Color
Probe qRT-PCR Buffer	990504a	500 µL	0.5 mL Vial	Blue
Probe qRT-PCR Enzyme	990504bv2	50 µL	0.5 mL Vial	Red
Template Dilution Buffer	180701	1 mL	1.5 mL Vial	Green
SbCMV Primer-Probe Powder	yp15-4320	50 T	1.5 mL Brown Vial	Brown
SbCMV Positive Control (1E7 copies/µL)	pc4320	0.5 mL	0.5 mL Vial	Yellow
Manual	sc15-4320	1 Set	NA	NA

Storage and Handling

Reagents are shipped on ice and should be stored at -20°C upon receipt. The kit is stable for at least one year from date of receipt. Repeated thawing and freezing of the kit components should be avoided. All components must be thawed at room temperature before use, placed on ice during use and stored at -20°C after use. Thawed components should be mixed well by gently inverting or gently vortexing before reaction setup.



Materials and Equipment Required but not Supplied in the Kit

Unless otherwise indicated, all materials are available through major laboratory suppliers.

Class	Items
General laboratory equipment and consumables	Benchtop microcentrifuge, micropipettors, vortex mixer, disposable powder-free gloves, sterile pipette tips with filters
Kit-specific laboratory equipment and consumables	Manual or automated RNA purification kits & equipments, real-time fluorescent PCR instruments and consumables, PCR reaction preparation station, known positive sample and negative sample as controls

Procedural Guidelines

- Use purified RNA as starting materials.
- Perform all steps at room temperature (20–25°C).
- Use sterile, disposable RNase-free pipette tips and microtubes.
- Wear disposable gloves while handling reagents and RNA samples.

Procedures

Section 1: Prepare 1E1 - 1E6 copies/μL serial dilutions from the Positive Control.

Note: Since the concentration of the SbCMV Positive Control is very high, the following dilution operations must be carried out in an independent area, and the samples or other components of this kit must not be contaminated at all. The Positive Control is a cDNA fragment from SbCMV and is not infectious.

1. Label six centrifuge microtubes as 6, 5, 4, 3, 2, and 1 respectively.
2. Add 45 μL of the Template Dilution Buffer into each tube. Use filtered pipette tips (the same applies hereinafter).
3. Transfer 5 μL of the Positive Control (provided in the kit, 1E7 copies/μL) into tube No. 6, and vortex vigorously for 1 minute. The concentration of the Positive Control in tube No. 6 is 1E6 copies/μL. Place the tube on ice for later use.
4. Change the pipette tip, transfer 5 μL of the diluent in tube No.6 into tube No. 5, and vortex vigorously for 1 minute. The concentration of the Positive Control in tube No. 5 is 1E5 copies/μL. Place the tube on ice for later use.
5. Change the pipette tip, transfer 5 μL of the diluent in tube No.5 into tube No. 4, and vortex vigorously for 1 minute. The concentration of the Positive Control in tube No. 4 is 1E4 copies/μL. Place the tube on ice for later use.
6. Repeat the above operation until six serial dilutions are obtained. Place them on ice for later use. They will be used as the templates for making the standard curve.

Section 2: Prepare samples and reagents

7. RNA purification: Perform N+2 RNA purification for N specimens per the guide from the manufacture of the RNA purification kit. For the two extra purification, One is for Purification Positive Control (PPC) using a known positive specimen as the starting material and the other is for Purification Negative Control (PNC) using a known negative specimen as the starting material. Store the purified RNA at -80°C until use.
8. Make Prime-Probe Mix: When using the kit for the first time, add 165 μL RNase-free Water into the microtube that contains the SbCMV Primer-Probe Powder. Vortex the microtube for 10 seconds and spin it for 10 seconds. The solution is SbCMV primer-Probe Mix. Put in ice for later use. The leftover should be stored at -20°C.
9. Calculate the total number of qRT-PCR reactions: For N samples, if quantitative analysis is to be performed and only one repeat is to be done for each sample, the recommended reaction number is $(N+2) \times 1 + 7 = N+9$. Among them, N + 2 reactions are for the N + 2 samples obtained in step 7, one is for the Amplification Negative Control (ANC, use water as the template), and six are for the six diluents obtained in step 6. If qualitative analysis is to be performed and only one repeat is to be done, the recommended reaction number is $(N+2) \times 1 + 2 = N+4$. Among them, N + 2 reactions are for the N + 2 samples obtained in t step 7, one is for the Amplification Negative Control (ANC, use water as the template), and another for the Amplification Positive Control (APC, use the dilution obtained in step 5 as the template). If more than one repeat is tested for each samples, the total reaction numbers should be recalculated accordingly.



Section 3: Set up qRT-PCR reaction

10. Make PCR premix: In a 1.5 mL microtube, add the three components according to the following table:

Component	For 1 reaction	For N+4 reactions	For N+9 reactions	For X reactions
Probe qRT-PCR Buffer	10 μ L	10 μ L $\times$ (N+5)	10 μ L $\times$ (N+10)	10 μ L $\times$ (X+1)
Probe qRT-PCR Enzyme	1 μ L	1 μ L $\times$ (N+5)	1 μ L $\times$ (N+10)	1 μ L $\times$ (X+1)
SbCMV Primer-Probe Mix	3 μ L	3 μ L $\times$ (N+5)	3 μ L $\times$ (N+10)	3 μ L $\times$ (X+1)
Total	14 μ L	14 μ L $\times$ (N+5)	14 μ L $\times$ (N+10)	14 μ L $\times$ (X+1)

11. Setup PCR reaction for quantitative analysis with one repeat for each sample: Add each component into the N+9 labeled tubes according to the following table. The positive control or the six diluents for standard curve should be added after all other samples are added and the tubes are capped:

Component	(N+2) Tubes	ANC Tube	Standard Curve Tubes No. 1 – 6
PCR premix from step 10	14 μ L each	14 μ L	14 μ L each
N+2 RNA Samples	6 μ L each	-	-
RNase-free Water	-	6 μ L	-
Six diluents from section 1	-	-	6 μ L each respectively

12. Setup PCR reaction for qualitative analysis with one repeat for each sample: Add each component into the N+4 labeled tubes according to the following table. The positive control or the six diluents for standard curve should be added after all other samples are added and the tubes are capped:

Component	(N+2) Tubes	ANC Tube	APC Tube
PCR premix from step 10	14 μ L each	14 μ L	14 μ L
N+2 RNA Samples	6 μ L each	-	-
RNase-free Water	-	6 μ L	-
1E4 copies/ μ L Dilution from step 5	-	-	6 μ L

Section 4: Run PCR

13. Perform PCR with the parameter described in the following table:

Process	Temperature	Duration	Cycle Number
RT	50°C	10 minutes	1 cycle
Denature	95°C	5 minutes	1 cycle
PCR	95°C	15 seconds	45 cycles
	60°C	30 seconds	
	72°C	1 minute, collect signal in FAM channel	

Section 5: Data Analysis and Interpretation

14. Validation of the test: After the RT-PCR is complete, inspect the amplification plot to ensure that the baseline threshold was set within the PCR exponential phase and above any background signal. For basic information about data analysis on specific real-time PCR instruments, please refer to the user manual of the respective instrument.
15. Validation of the purification experiment: If the PPC result is positive and the PNC result is negative, the RNA Purification process is valid. Move on to next step. If the PPC reaction is negative or the PNC result is negative, the whole RNA Purification process is invalid. There is no need to further analyze the data of the sample. The RNA Purification process must be repeated. The possible reasons of experimental failure include the disfunction of the RNA purification kit, mistakes in experimental processes, failures of PCR machine, or carry-over contamination of the environment from previous experiments.



16. Validation of the amplification experiment: If the APC result is positive and the ANC result is negative, the RT-PCR amplification process is valid. Move on to next step. If the APC result is negative or the ANC result is positive, the whole RT-PCR amplification experiment is invalid. There is no need to further analyze the results of the samples. The reason for RT-PCR failures must be found. The possible reasons include the disfunction of the RT-PCR amplification reagents and the failure of PCR instruments, or the carry-over contamination of the environment or of the reagents.
17. If both purification and amplification experiment are valid, then analyze the results of the samples. For quantitative analysis, take the log value of the concentration of the six standard curve dilutions as the horizontal axis and the valid Ct value as the vertical axis to draw a standard curve. Then, use the valid Ct value of the samples to be tested to calculate the log value of the RNA concentration from the standard curve, and then convert it to the RNA concentration in copies/ μ L.
18. For qualitative analysis, if there is no Ct value or the Ct value is greater than or equal to 40, the sample is negative. If the Ct value is less than 40, the sample is positive.

Limited Product Warranty

Skygen, Inc. warrants its products under the terms specified in the Skygen General Terms and Conditions of Sale, available at biofargo.com. Warranty coverage may vary depending on the product type and region.

This product is intended for research use only. It is not intended for therapeutic or diagnostic use in humans or animals.

If you have any questions regarding product selection, application, or warranty coverage, please contact us via biofargo.com for professional support.

- The information in this guide is subject to change without notice.
- This product is intended for research purposes only. It is not intended to be used for therapeutic and diagnostic purposes in humans or animals.
- DISCLAIMER: TO THE EXTENT ALLOWED BY LAW, SKYGEN INC. WILL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, INDIRECT, PUNITIVE, MULTIPLE, OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THIS DOCUMENT, INCLUDING YOUR USE OF IT.